



Analysis of CO₂ electrolysis devices via a carbon balance and in-situ synchrotron based approaches.

Brian Seger SurfCat Summer School August 11, 2022, right before lunch



Electric Cars





Carbon Based Products





What are we trying to do it



• Chemicals are 7% of EU's greenhouse gasses emissions



• If all of Europes's electricity went to ethylene production (@ 2V electrolysis), we would only produce 67% of world's ethylene.

Industrial relevant approaches to CO₂ electrolysis







3 mm anolyte & catholye

Burdyny and Smith, E&ES, 12, 1442—1453, (2019)

Disadvantages:

Kibria, et. al, Adv. Mat., 1807166, (2019)

Electrochemical set-up





Anode: IrO₂ on carbon paper Membrane: Sustainion 37-50 AEM Temperature: 30 C



Cathode: silver membranes of 50 µm thickness



Issues with outlet flow rate





Inaccurate

(? Δ in conductivity)

Gas	Thermal Conductivity (W/m K)
CO ₂	0.017
СО	0.025
H ₂	0.18



Inaccurate

(? Δ in viscoscity)

Gas	Viscosity (10 ⁻⁵ Pa s)	
CO ₂	1.47	
СО	1.74	
H ₂	0.88	

Issues with outlet flow rate



• It is not straightforward to measure outlet flow rate



Soap bubble (positive displacement)

Accurate (Positive Displacement) MESA Labs- Defender 530

Accurate (Buoyancy) Bioprocess Control µFlow





$$Q_{\text{gas,out}} = Q_{\text{gas,in}} - \frac{RT}{PF} \left[\sum_{0}^{i} I_{i} \frac{\#C_{\text{liq,i}}}{\#e_{\text{liq,i}}^{-}} + \sum_{0}^{j} I_{j} \left(\frac{\#C_{\text{gas,j}} - 1}{\#e_{\text{gas,j}}^{-}} \right) + A \left(I_{Total} - \frac{1}{2} I_{Formate} - \frac{1}{8} I_{acetate} \right) \right]$$

Measuring cathodic products



- Using Ag membranes as catalysts gave good, but not great performance.
- We attributed unknown partial current density to formate.
- By measuring our cathodic outlet flow, we were able to determine an 'A' value.





Larrazabal, G., et al., Account. Mat. Res., 2021

Larrazabal, G., et al., Appl. Mat. & Int., 2019

Measuring anodic products

- By measuring our anodic outlet flow we can get the amount of oxygen produced.
- We can correlate our CO₂/O₂ ratio to what species is predominately going through the membrane.





Larrazabal, G., et al., Account. Mat. Res., 2021

Total system analysis



• 100% faradaic efficiency is great to see

• Full carbon balance is just as important to see.



Larrazabal, G., et al., ACS Appl. Mat & Int., 2019





- We never produce formate, but rather <u>postassium</u> formate
- Where does the K⁺ come from?
- $KHCO_3$ is usually the source.

 $KHCO_3 + CO_2 \rightarrow KCOOH + \frac{1}{2}O_2 + CO_2$

Name	Value (\$/Kg) Aldrich	Value (\$/kmole)
Potassium bicarbonate	120	1.20
Potassium formate	100	1.19

Analyzing copper for CO₂ reduction

- With copper producing liquid products, we decided to go with a GDE approach.
- 70 nm sputtered Cu on a gas diffusion layer.

Anolyte

Gas outlet: gas mixture

Gas inlet: CO₂ 45 ml/min

GC

Flow meter

Exhaust

50 ml

KHCO







Testing different electrolytes

- We tested in both neutral and basic electrolytes.
- Basic electrolytes are effectively 'CO₂ scrubbers'

 $CO_2 + OH^- \rightarrow HCO_3^-$ pKa (effective)=7.8 $HCO_3^- + 2OH^- \rightarrow CO_3^{2-} + H_2O$ pKa = 10.3

- Even at open-circuit, significant CO₂ is consumed.
- CO₂ reduction naturally produces OH⁻, thus increasing 'scrubbing' capability of catholyte gas

 $CO_2 + H_2O + 2 e^- \rightarrow CO + 2 OH^-$





Comparison of selectivites in different electrolytes





• How important is it to take into consideration actual gas flow rate leaving reactor?



Liquid selectivites

- We see 8 different liquid products
- Minimal variation at different current regimes.
- We see significant products coming out the anode.



Gas

outlet:

gas mixture



Understanding membrane crossover



Proposed carbon balance paths via CO_3^2 or HCO_3^- formation from CO_2 and a subsequent CO_2 production from CO_3^2 or HCO_3^-

Anode reactions:

<u>CO₂/O₂ ratio</u>



 $4CH_3COO^- \rightarrow 4CH_3COOH + O_2 + 4e^- \longrightarrow 0$







pKa of $HCO_3/CO_2 = 7.8$

• Did our 'A' value line up with our CO_2/O_2 ratio



- With basic electrolytes there is no CO₂ emitting from anolyte.
- A smaller reservoir shows CO₂ just needs to satruate the solution.



Device analysis

• 100% faradaic efficiency

• Full carbon balance



Inlet CO₂ flow: 45 ml/min

 $\phi_{inlet CO_2} = \phi_{unused CO_2} + \phi_{CO_2 to gas} + \phi_{CO_2 to liquid} + \phi_{out the anode}$

J	Ø _{unused CO2}	$\phi_{CO_2 to gas}$	$\phi_{CO_2 to liquid}$	Ø _{Anode}	$\phi_{total CO_2}$
(mA/cm ²)	(ml/min)	(ml/min)	(ml/min)	(ml/min)	(ml/min)
200	40.806	0.922	0.3387	3.11156	45.178
250	39.735	1.169	0.3928	3.80596	45.103
300	38.616	1.379	0.4779	4.50385	44.977

Using 1 M KHCO₃ as initial electrolyte

We still screwed up our analysis ?

- If we have a cell with 50 mL catholyte when we start, when we finish can we multiply our HPLC/NMR liquid product data on a final water volume of 50 mL?
- When carbonates transfer across the membrane it brings with it a lot of water
- We found the water crossover matches the free ion hydration number
- In other words, water transfer is membrane independent.



Ma, et al. ACS Energy Letters, 2022

How big of a screw up is this?

- The overestimation is not that big for shorter time period operations
- If a cation exchange membrane is used, non-compensated membranes will lead to an underestimation of produts



Ma, et al. ACS Energy Letters, 2022

How do CEM & Bipolar membranes compare ?

- Selectivity does not vary as long as you have a gapped cell (1cm for us).
- The CO₂ crossover is quite different.



Total cell voltage

- Ohmic resistance in electrolytes dominate cell voltage.
- Conductivity does not account for watersplitting in BPM.
- CO electrolysis does not have these issues.





Varying alkalinity for CO electrolysis

- Transient tests (1 hour) allowed us to see the effects of pH
- Acetate increases whereas other C₂ products decrease as alkalinity increses
- Ethanol seems to decrease faster than ethylene
- Trends seem to be related to linear shift (rather than logarithmic) with alkaline concentrations.



Ma et al., E&ES, 2022









Understanding Degradation Mechanisms

Understanding oscillations



- It is well known in the field that H₂ evolution increases over time
- It is thought that this is due to water 'flooding' into the cathode preventing CO₂ mass transfer.
- Sometimes oscillations come with this.



Is water 'flooding' our catalyst ?



Designing a synchrotron experiment

- We thought excess water may prevent efficient CO₂ mass transfer to the catalyst
- We used synchrotron X-ray scattering at ESRF to analyse this.



*CO*₂ *Reactor*











Experiments







Analysing copper in our device

- We can easily see the change in the surface oxide in Cu being reduced.
- We can also monitor Cu as a function of height within the gas diffusion layer





Analysing water

- By using variations in background signal in q-space where there are no Bragg peaks, we can use this as a proxy for water content.
- We can relate water content to potential variations.
- Lower potential, more water, more hydrogen.





-

Analysing CO₂ to O₂ ratio

• In a different experiment we measured CO₂ to O₂ ratio

• We notice the CO₂ to O₂ ratio decreases as the potential decreases

- Membranes are 2.5x more conductive with OH⁻ compared to CO₃²⁻ transferring.
- This also means are cathode is being starved of CO₂.



Mass transfer issues

- When looking at salts we see KHCO₃, but no K₂CO₃
- We see the salt deposition before water floods the cell



<u>100 mA/cm²</u>



Conclusions

- husia
- Engineering CO₂ electrolysis will be much more complex than water electrolysis.
- The field is understanding and adapting quite quickly.







Larrazabal, G., et al., Appl. Mat. & Int., 2019

Acknowledgements

The VILLUM Center for the Science of Sustainable Fuels and Chemicals

THE VELUX FOUNDATIONS

VILLUM FONDEN 💥 VELUX FONDEN



ESRF Collaborators





Jakub Drnec

Marta Mirolo

Roosa Ilvonen



Gaston Larrazabal







Asger Moss



Sahil

Garg



Carlos Rodriguez



To learn more about our research







Yu Qiao



MARIE CURIE



Clara Jensen



Wanyu Deng



Collaborators

Ib Chorkendorff Kasper Therkildsen

Qiucheng Xu

X-ray impact

- The X-rays had no noticeable impact on our selectivity.
- We also did some experiments at DTU and some at ESRF with no noticeable change.

